SITECOM

Register this product online within 3 weeks of purchase and get a free **10 year** warranty

www.sitecom.com/warranty

Designed in Europe

RoHS compliant

Installation guide


PC or Mac

Wi-Fi range extender N300

UK Full manual available in English
NL Volledige handleiding beschikbaar in het engels
IT Il manuale utente completo è disponibile in lingua inglese
DE Vollständiges Handbuch in englischer Sprache verfügbar
ES Manual completo disponible en inglés
PT Manual completo disponível em inglês
FR Manuel complet disponible en anglais
RU Подробное руководство доступно на английском языке

www.sitecom.com/helpdesk

Have the **network login details** ready


Network login details. Keep this safe!

Wi-Fi range extender | WLX-2006 v1 001

Range Extender configuration

Type the following IP address in your web browser: **http://sitecom.extender**

Username: **admin**

Password: **admin**

Wirelessly connect to this Range Extender

Network name: sitecomXXXXXX

!

UK The Extender's wireless network name (SSID) changes to your existing Wi-Fi network name, with _EXT at the end of the name.
FR Le nom de réseau sans fil (SSID) de l'Extender reprend le nom de votre réseau Wi-Fi existant, complété du suffixe _EXT.
DE Der WLAN-Name (SSID)des Extenders wird auf den Namen des bestehenden WLANs geändert, und es wird _EXT angehängt
NL De naam van het draadloze netwerk (SSID) van de Extender verandert in je bestaande WiFi-netwerknaam en heeft de aanduiding _EXT aan het einde van de naam.
IT Il nome della rete dell'Extender (SSID) prenderà il nome della tua rete wireless con il suffisso _EXT
ES El nombre de la red inalámbrica del amplificador de señal (SSID) cambia a su nombre de red Wi-Fi actual, con el sufijo_EXT al final del nombre.
PT O nome da rede sem fios do Ampliador(SSID) muda para o nome da rede Wi-Fi existente, com _EXT no fim do nome.
RU Имя беспроводной сети расширителя (SSID) изменится на существующее сетевое имя Wi-Fi с _EXTна конце имени.


Serial No.:


SITECOM

1

Positioning range extender

NL Plaatsing van de Range Extender
IT Posizionamento del Range Extender
DE Range Extender aufstellen
ES Posicionamiento del extensor de rango
PT Posicionar o Range Extender
FR Positionnement du Range Extender
RU Расположение расширителя беспроводного диапазона





2

Range extender configuration

NL Configuratie van de Range Extender
IT Configurazione del Range Extender
DE Konfiguration des Range Extenders
ES Configuración del extensor de rango
PT Configuração do Range Extender
FR Configuration du Range Extender
RU Конфигурация расширителя беспроводного диапазона

Choose one of the two options:

NL Kies één van de twee opties:
IT Scegli una delle due opzioni sequenti:
DE Wählen Sie eine der beiden Optionen:
ES Escoja una de las dos opciones:
PT Escolha uma das duas opções:
FR Choisissez une des 2 options:
RU Выберите один из двух вариантов:

Option 1:

Range Extender configuration via push button

In combination with a (Modem) Router with OPS/WPS

NL Optie 1: Range Extender configuratie met een druk op de knop
In combinatie met een (Modem) Router met OPS/WPS

IT Opzione 1: Configurazione del Range Extender via push button
In combinazione con un (Modem) Router con OPS/WPS.

DE Option 1: Range Extender per Knopfdruck konfigurieren
In Verbindung mit einem (Modem) Router mit OPS/WPS


ES Opción 1: Configuración del Repetidor de Señal pulsando el botón
En combinación con un (Modem)Router con OPS/WPS

PT Opção 1: Configuração do Amplificador de Sinal através de botão de pressão Em combinação com um Router (Modem) com OPS / WPS

FR Option 1: configuration commutateur par bouton
en combinaison avec un (modem) routeur équipé du ops / wps.


RU 1 Настройка Расширителя диапазона нажатием кнопки
сочетании с функцией OPS/WPS (модема) роутера

A



Push **2** seconds

B




Push **2** seconds


Go to step 3

Option 2:

Range Extender configuration via wizard


A






NL Optie 2: Range Extender configuratie via wizard
IT Opzione 2: Configurazione del Range Extender via wizard.
DE Option 2: Range Extender mit Hilfe des Wizards konfigurieren
ES Opción 2: Configuración del Repetidor de Señal con el asistente
PT Opção 2: Configuração do Amplificador de Sinal via assistente/operador
FR Option 2: configuration commutateur par set-up wizard
RU 2 Настройка Расширителя диапазона через мастера настройки


B




Network login details. Keep this safe!
Wi-Fi range extender | WLX-2006 v1 001
Range Extender configuration
Type the following IP address in your web browser: http://sitecom.extender
Username: admin
Password: admin
Wirelessly connect to this Range Extender
Network name: sitecomXXXXXX
Serial No.:
SITECOM



Not connected
Connections are available
Wireless Network Connection
sitecomXXXXXX
Other network 1
Other network 2
Other network 3
Other network 4
Other network 5
Other network 6
Other network 7
Open Network and Sharing Center
click
click
PC




Wi-Fi: On
Turn Wi-Fi Off
No network selected
Other network 1
Other network 2
sitecomXXXXXX
Other network 4
Other network 5
Other network 6
Other network 7
Other network 8
Other network 9
Other network 10
Join Other Network...
Create Network...
Open Network Preferences...
click
Mac




Network login details. Keep this safe!
Wi-Fi range extender | WLX-2006 v1 001
Range Extender configuration
Type the following IP address in your web browser: http://sitecom.extender
Username: admin
Password: admin
Wirelessly connect to this Range Extender
Network name: sitecomXXXXXX
Serial No.:
SITECOM

C





PC
= OK




Thu 15 44
= OK
Mac


D


type: http://sitecom.extender
Open your browser
PC



type: http://sitecom.extender
Open your browser
Mac

E


User name: admin
Password: admin
Windows Security
User name
Password
Remember my credentials
OK
Cancel
click OK
PC



User name: admin
Password: admin
ADSL Router/Modem
Name:
Password:
Remember this password in my keychain
Cancel
click Log in
Mac

F



wallmount range
extender N300
SITECOM
Home
Wizard
Basic Settings
Advanced Settings
Toolbox
Choose your language
System
Hardware version
Runtime Code Version
Wireless Configuration
Mode : Universal Repeater
ESSID :
Channel Number : 11
Security : Disabled
BSSID : 80:1F:02:3A:82:5E
Associated Clients : 0
click
wizard

G




Select your original
Wi-Fi network
SITECOM
Choose your language
the wireless network that you want to extend.
SSID
Channel
Encryption
Signal
Sitecom436056
11
WPA2-PSK
68
SitecomF2795E
5
WPA2-PSK
56
Sitecom829EFC
11
WPA2-PSK
24
PConTV
1
no
8
Refresh
Next
click
Next

H




wallmount range
extender N300
Type your original Wi-Fi password
Home
Wizard
Basic Settings
Advanced Settings
Wireless Security
Please enter the security key for the wireless network that you want to
Pre-Shared Key :
Next
Previous Page
Cancel
click
Next

I



wallmount range
extender N300
SITECOM
Home
Wizard
Basic Settings
Advanced Settings
Toolbox
Choose your language
Please reconnect to the following network:
ESSID :
SitecomAAB158_EXT
Pre-Shared Key :
wirelesspassword
Copy to Clipboard
Apply
Previous Page
Cancel
click
Apply


J



K







UK Confirm the position with the signal strenght LED.
Solid green: ideal position, **blinking green:** move range extender closer to the (modem) router.

FR Vérifiez la position à l'aide de la diode électroluminescente d'intensité du signal. **Allumée en vert**: position idéale, **clignotante en vert**: rapprochez le Range Extender du routeur (ou du modem-routeur).

DE Überprüfen Sie die Position mit der Signalstärke-LED.
Konstant grün: ideale Position, **grün blinkend:** verkleinern Sie den Abstand zwischen Range Extender und (Modem) Router.

NL Controleer de positie met de LED-signaalindicator.
Brandt groen: optimaal. **Knippert groen**: plaats Range Extender dichter bij router (modem).

IT Verificare la posizione con il LED di potenza del segnale.
verde fisso: posizione ideale; **verde lampeggiante**: spostare l'estensore di portata avvicinandolo al (modem) router.

ES Confirme la posición con el LED de fuerza de señal.
verde intenso: posición ideal, **verde parpadeante**: mover el extensor de rango más cerca del (módem) router.

PT Confirme a posição com o LED indicador de força do sinal.
verde aceso: posição ideal, **verde a piscar**: aproxime o range extender do (modem) router.

RU Проверьте правильность положения с помощью индикатора мощности сигнала. **Постоянный зеленый**: идеальное положение; **мигающий зеленый**: переместите расширитель диапазона ближе к маршрутизатору (модему).


Go to step 3


3

Connect to your PC / Mac


NL Aansluiten op je PC / Mac
IT Connetti al PC / Mac
DE Verbindung zum PC / Mac
ES Conéctese a su PC / Mac
PT Ligue ao seu PC / Mac
FR Peut être connecté à votre ordinateur PC / Mac
RU Подключитесь к PC / Mac


A





B





!

UK The Extender's wireless network name **(SSID)** changes to your existing Wi-Fi network name, with **_EXT** at the end of the name.

FR Le nom de réseau sans fil **(SSID)** de l'Extender reprend le nom de votre réseau Wi-Fi existant, complété du suffixe **_EXT**.

DE Der WLAN-Name **(SSID)** des Extenders wird auf den Namen des bestehenden WLANs geändert, und es wird **_EXT** angehängt.

NL De naam van het draadloze netwerk **(SSID)** van de Extender verandert in je bestaande WiFi-netwerknaam en heeft de aanduiding **_EXT** aan het einde van de naam.


IT Il nome della rete dell'Extender **(SSID)** prenderà il nome della tua rete wireless con il suffisso **_EXT**.


ES El nombre de la red inalámbrica del amplificador de señal **(SSID)** cambia a su nombre de red Wi-Fi actual, con el sufijo **_EXT** al final del nombre.

PT O nome da rede sem fios do Ampliador **(SSID)** muda para o nome da rede Wi-Fi existente, com **_EXT** no fim do nome.


RU Имя беспроводной сети расширителя **(SSID)** изменится на существующее сетевое имя Wi-Fi с **_EXT** на конце имени.


C


Type your original Wi-Fi password
Connect to a Network
Type the network security key
Security key:
Hide characters
OK
click OK
PC


Type your original Wi-Fi password
WPA2 password.
Password:
Show password
Remember this network
Cancel
click Join
Mac

D


PC
= OK


Thu 15 44
= OK
Mac


E



Done. Enjoy!

Indication of the LEDs

NL	Indicatie van de LED’s	**PT**	Indicação dos LEDs
IT	Indicatori LED	**FR**	Signification des diodes
DE	LED-Anzeigen	**RU**	Индикация на светодиодах
ES	Indicación de los LED		



Press **2** sec. = OPS mode
Press **15+** sec. = Reset

Trouble? www.sitecom.com/helpdesk